Plug In Craftsman LED Worklight I.S. 10/5/06 9:37 AM Page 1

Maintenance
Before performing any maintenance, **ALWAYS** unplug worklight. Remove dirt and grime as soon as it accumulates. Use a soft, damp cloth and a mild soap, if needed. Be sure not to get the electrical plug wet. **NEVER** submerge any part of the worklight in any solution to clean it. **DO NOT USE** solvents such as gasoline, turpentine, etc. to clean unit. Aerosols and other chemicals may fog the clear polycarbonate lens.

One Year Full Warranty on Worklight
If this product fails due to a defect in material or workmanship within one year from the date of purchase, **RETURN IT TO YOUR NEAREST SEARS STORE OR CRAFTSMAN OUTLET IN THE UNITED STATES**, and it will be replaced free of charge. This warranty applies for only 90 days from the date of purchase if this Craftsman Worklight is used for commercial or rental purposes. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

Sears, Roebuck and Co., Hoffman Estates, IL 60179 USA
Assembly or operation questions? Call 1-800-334-6871
www.craftsman.com 9/2006

Printed in China
325-1584

Owner's Instructions

CRAFTSMAN®

Caution: Read all instructions and warnings before operating.

SAVE THESE INSTRUCTIONS! READ ALL INSTRUCTIONS!

NOTE: ***To avoid serious injury or death from electrical shock or fire:***

1. **DO NOT** handle this fixture or try to plug it in when your hands are wet or damp or when you are standing on a wet or damp surface or in water.
2. This fixture **MUST ALWAYS BE USED** in accordance with all electrical and safety codes and ordinances, including the most recent National Electric Code (NEC) and with the Occupational Safety and Health Ace (OSHA) Volume 1 on General Industry Standards and interpretations.
3. **ALWAYS** make certain that the power source conforms to the requirements on the fixture.
4. **DO NOT** disassemble fixture. The fixture does not have any user serviceable parts.



LED Work Light
Model No. 73903

CRAFTSMAN®

5. This fixture **IS ONLY FOR USE ON 110-120V AC** circuits.

6. **FIXTURE IS NOT WATERPROOF** and is not intended for use in showers, saunas, or in potentially wet locations. ALWAYS keep this fixture away from sinks, tubs, showers, etc. **NEVER ATTEMPT TO PICK UP PLUGGED-IN APPLIANCES WHEN THEY FALL INTO WATER BECAUSE FATAL ELECTROCUTION COULD RESULT.**

7. This fixture is intended for use as a general indoor lighting. **DO NOT** use in potentially dangerous locations, such as flammable or explosive atmospheres.

8. **NEVER** operate the light with the clear protective lens removed.

9. **KEEP OUT OF REACH OF CHILDREN.**

10. **KEEP AWAY** from excessive heat or flame.

11. **DO NOT** short the positive-negative terminals together.

12. **DO NOT** look directly into the light.

Operation
1. Plug power cord into any 110-120V AC standard wall outlet.
2. Depress switch in the handle one time to turn on the LED lights.
3. Depress switch a second time to turn off the LED lights

Hanging Utility Light
1. Hanging hook can rotate 360°.